



. Mount the VIP-480L paging speaker.

. Select location for biscuit block near VIP-480L paging speaker. The cable attached to the speaker will have to reach the biscuit lock).

. Connect the VIP-480L network interface unit to the biscuit block using Cat 3/5/6 cable as shown above.

4. Connect the VIP-480L network interface unit to the network. A Cat 5 patch cord is included for this connection, but up to 300 feet of cable may be used if necessary for your application.

5. Program the VIP-480L using the VIP-102 IP Solutions Setup Tool (included on CD ROM).